


Replacement parts breakdown for Aquabar 2



ITEM	POVC2LRHK-AW001	POC2LRHK-AW001	POU2LRHK-AW001	DESCRIPTION
1	036369-002	036369-002	036369-001	ALCOVE, FAUCET
2	036344-001	036344-001	036344-001	BAFFLE
3	022753-002			BALLAST
4	036648-001	036648-001	036648-001	BASE ASSEMBLY, PLASTIC
5	036370-002	036370-002	036370-001	BRACKET, BUTTON MOUNTING
6	036438-001	036438-001	036438-001	BRACKET, ELBOW HOLDER
7	036458-002	036458-002	036458-001	BRACKET ASSY, PCB & DISPLAY
8	036445-001	036445-001	036445-001	BUTTON, RESET, LOGO
9	036439-001	036439-001	036439-001	CLIP, SILICONE ELBOW
10			027040-055	COLD CONTROL
11	036027-001	036027-001	036027-001	COMPRESSOR ASSY, HUAYI AES-25-DS
12	036352-001	036352-001	036352-001	DOOR, FILTER ACCESS
13	036353-002	036353-002	036353-001	DRIP TRAY
14	036354-001	036354-001	036354-001	DRIP TRAY GRILLE
15	036443-002	036443-002	036443-002	ELBOW, MANIFOLD, SILICONE
16	028481-101	028481-101	028481-101	ELBOW, PP 1/4" OD UNION
17	033347-001	033347-001	033347-001	FILTER, AIR
18	033598-005	033598-005	033598-005	FLOW MONITOR
19	036095-003	036095-003	036095-003	FOOT PAD
20	036647-002	036647-002	036647-001	FRONT PANEL, CENTER
21	036351-001	036351-001	036351-001	FRONT PANEL, UPPER
22	036442-002	036442-002	036442-002	GASKET, SS RESERVOIR LID
23	036654-001	036654-001	036654-001	HANDLE, REAR
24	036654-001	036654-001	036654-001	HANDLE, SIDE
25	036654-001	036654-001	036654-001	HOT TANK
26	036655-001	036655-001	036655-001	INSULATION SET, HOT TANK
27	036338-001	036338-001	036338-001	INSULATION SET, RESERVOIR
28	036349-001			LEAK CONTROLLER
29	036487-001	036487-001	036487-001	LID ASSEMBLY, FLOAT
30	036346-001	036346-001	036346-001	LID ASSEMBLY, SS
31	036356-101	036356-101	036356-101	MANIFOLD ASSY
32	020496-001	020496-001	020496-001	NUT PLATE
33	036442-001	036442-001	036442-001	O-RING, PLASTIC LID
34	036055-001	036055-001	036055-001	OVERLOAD (HUAYI)
35		036453-001	036453-001	PLUG, BAFFLE & UV NUT
36	036609-001	036609-001	036609-001	PLUG, SILICONE DRAIN
37	036360-001	036360-001	036360-001	PUSHBUTTON, COLD
38	036361-001	036361-001	036361-001	PUSHBUTTON, COOK
39	036650-001	036650-001	036650-001	PUSHBUTTON ASSY, HOT, W/ SAFETY
40	035113-003			QUARTZ SLEEVE ASSY, UV
41	036056-001	036056-001	036056-001	RELAY (HUAYI)
42	036348-001	036348-001	036348-001	RESERVOIR ASSY W/ HEAT EXCHANGER
43	036366-001	036366-001	036366-001	RDD, VALVE, COOK
44	036364-001	036364-001	036364-001	RDD, VALVE, COLD
45	036365-001	036365-001	036365-001	RDD, VALVE, HOT
46	036485-002	036485-002	036485-001	SIDE PANEL ASSY, LEFT
47	036486-002	036486-002	036486-001	SIDE PANEL ASSY, RIGHT
48	036363-001	036363-001	036363-001	SPOUT NOZZLE
49	027638-009	027638-009	027638-009	SPRING, BUTTON
50	027638-010	027638-010	027638-010	SPRING, RESET BUTTON
51	036437-001	036437-001	036437-001	STOP, BUTTON SPRING
52			029545-006	SWITCH, HOT TANK
53	036646-001	036646-001	036646-001	TOP ASSY, CABINET
54	035126-002			UV BULB & QUARTZ SLEEVE ASSY
55	033562-003			UV BULB ASSY
56	036653-001	036653-001	036653-001	WHEEL ASSY

ITEMS NOT SHOWN

POVC2LRHK-AW001	POC2LRHK-AW001	POU2LRHK-AW001	DESCRIPTION
035935-001	035935-001	035935-001	HT9A SERVICE KIT, ELEMENT
		035935-002	HT9A SERVICE KIT, CONTROLS
036101-101	036101-101		NTC COLD
036101-102	036101-102		NTC HOT
		033588-002	THERMOSTAT, HOT
033588-003	033588-003	033588-003	THERMOSTAT, HOT LIMITER
035807-001	035807-001	035807-001	TUBE, TYGOPRENE